

"Click Here" to Read More About This Manual

[Bose SoundLink Flex User Manual](#)

Website: <https://manuals.plus/bose/bose-soundlink-flex-user-manual>



New Bose Soundlink Flex Bluetooth Portable Speaker,

Wireless Waterproof Speaker for
Outdoor Travel

User Manual

Product Description

The SoundLink Flex Bluetooth speaker does more than just immerse you – it provides a strong connection to your music. With crisp audio free of distortions, you'll hear every instrument on the track and nuance in the vocals. It doesn't matter how the portable speaker is positioned: PositionIQ technology detects its orientation and ensures the best sound.

The portable Bluetooth speaker is packed with exclusive technologies. The transducer offers clear sound and deep bass. Its digital signal processing technologies, proprietary code, and custom algorithms work together for ideal sound quality wherever you are. Really, wherever, since the SoundLink Flex is an IP67 waterproof speaker.

Its exterior can handle falls, the coat won't peel or flake, and it resists corrosion and UV light. It's also easy to hold or store, and you can secure the outdoor speaker with its utility loop. Rigorously tested to meet an IP67 rating, the SoundLink Flex is waterproof. It floats, too, so it won't sink if it falls off your boat. For added protection from dust and debris, the Bluetooth speaker is crafted and sealed with waterproof materials. Plus, to ensure it can travel with you, Bose subjected the outdoor speaker to water, temperature, and drop tests. These proved that it's durable enough for anything.

The battery offers up to 12 hours of unplugged play time. The Bose Connect app lets you customize the portable speaker settings, update software, and more. If your phone isn't nearby, press and hold a button on the IP67 waterproof speaker to access your phone's Siri or Google Assistant. A built-in microphone means you can also take and make phone calls through the SoundLink Flex.

It also connects to other Bluetooth devices within 30 feet for even bigger sound.



About This Item

- **State-of-the-art Design** – SoundLink Flex outdoor speaker is packed with exclusive technologies and a custom-engineered transducer for deep, clear, and immersive audio at home or on the go
- **Clearest Possible Sound** – Proprietary Position Qtechnology automatically detects the position of your portable Bluetooth speaker for optimal sound quality in any orientation or environment
- **Waterproof Wireless Speaker For Travel** – SoundLink Flex is rigorously tested to meet IP67 waterproof speaker standards. Crafted and sealed with waterproof materials, it even floats – ideal for outdoor adventures
- **Portable Bluetooth Speaker** – Built to resist water, dust, and debris, in a design that withstands drops and rust, this compact speaker goes wherever you do. It's also easy to hold and store, and resistant to corrosion and UV light
- **Rechargeable Wireless Speaker Battery** – Portable speaker charges through USB-C cable (included). Lithium-ion battery offers up to 12 hours of life per charge
- **Built-in Microphone** – You can make and receive calls through the portable Bluetooth speaker. Just one button accesses your phone's Siri or Google Assistant voice input
- **Bluetooth Wireless Speaker** – SoundLink Flex pairs with Bluetooth-enabled devices like phones and additional Bose speakers within a range of 30 feet
- **Bose Connect App** – App automatically updates the portable Bluetooth speaker with the latest software, allows you to customize settings, unlock product features, and more



Product Information

• Product Dimensions	2.06 x 7.93 x 3.56 inches
• Item Weight	1.3 pounds
• Manufacturer	BOSE
• ASIN	B099T738ZC
• Item model number	865983-0200
• Batteries	1 Lithium ion batteries required. (included)

Included With Purchase

Speaker	1
USB-cable	1



Connectivity

SoundLink Flex pairs with Bluetooth-enabled devices like phones and additional Bose speakers within a range of 30 feet, thereby enabling you to enjoy your music.

Battery Indicator

The device shows the battery charge level. Each time you power on your speaker, the battery indicator displays the battery charge level for two seconds and a voice prompt

[Announces the battery charge level.](#)

To check the battery charge level, press and hold the power button while checking the battery indicator.

Indicator Activity	System State
Solid green	Charged / medium to full charge
Blinking amber	Charging
Solid amber	Medium charge
Blinking red	Need to charge

Bluetooth indicator

The device Shows the connection status

Indicator Activity	System State
Blinking blue	Ready to pair
Blinking white	Connecting
Solid white	Connected

Important Safety Instructions

- Never attempt to charge the speaker while it is wet. Doing so may cause damage to the speaker.
- If the speaker is exposed to salt or chlorinated water, gently rinse with fresh water following the exposure to remove residue. Make sure the connector port is fully dried out before charging.
- Do NOT submerge this speaker in any pool of water deeper than 3.3 ft (1 m).
- Do not use any solvents, chemicals or cleaning solutions containing alcohol, ammonia or abrasives.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.